




# R503/R503-M22 Fingerprint Module User Manual



**Hangzhou Grow Technology Co., Ltd.**

2023.09 Ver: 1.4.1

## Preface & Declaration

Thank you for your selection of R503/R503-M22 Fingerprint Identification Module of GROW.

The Manual is targeted for hardware & software development engineer, covering module function, hardware and software interface etc. To ensure the developing process goes smoothly, it is highly recommended the Manual is read through carefully.

Because of the products constantly upgraded and improved, module and the manual content may be changed without prior notice. If you want to get the latest information, please visit our company website ([www.hzgrow.com](http://www.hzgrow.com)).

We have been trying our best to ensure you the correctness of the Manual. However, if you have any question or find error, feel free to contact us or the authorized agent. We would be very grateful.

The Manual contains proprietary information of Hangzhou Grow Technology Co., Ltd., which shall not be used by or disclosed to third parties without the permission of GROW, nor for any reproduction and alteration of information without any associated warranties, conditions, limitations, or notices.

No responsibility or liability is assumed by GROW for the application or use, nor for any infringements of patents or other intellectual property rights of third parties that may result from its use.

[www.hzgrow.com](http://www.hzgrow.com)

## Revised Version

| Version Number | Date    | Revise Content  | Modifier  |
|----------------|---------|---|-----------|
| V1.2           | 2021.10 | 1. LED colors increased from three to seven, and the instruction formats were downward compatible.<br>2. Added 0x31 automatic registration template: the upper computer can automatically collect 6 images by sending only one command, and then generate templates for saving.<br>3. Added 0x32 automatic fingerprint verification: the upper computer can only send one command to realize image collection, generate features, search and compare the fingerprint database, and return the comparison results<br>4. Added template upload procedure flow<br>5. Added template download process | Grow Tech |
| V1.2.1         | 2022.03 | 1. Added Power Supply Requirements,Ripple noise<br>2. Update Command: The note of UpChar and DownChar   | Grow Tech |
| V1.2.2         | 2022.10 | 1. Added Buffer contents  | Grow Tech |
| V1.3           | 2023.06 | 1. Added Basic communication flow and general instruction communication flow<br>2. Updated Acknowledge package format of Read product information Command (0x3C)<br>3. Updated Automatic fingerprint verification Command (0x32)<br>4. Updated Automatic registration template Command (0x31)   | Grow Tech |
| V1.4           | 2023.07 | 1. Added R503-M22 Size Version  | Grow Tech |
| V1.4.1         | 2023.09 | 1. Updated Security level,Checksum<br>2. Added example instruction for AuraLedConfig, AutoEnroll, AutoIdentify  | Grow Tech |

# Catalog

|     |   |        |
|-----|---|--------|
| I   | Introduction .....  | - 1 -  |
|     | Operation Principle .....   | - 1 -  |
| II  | Hardware Interface .....  | - 2 -  |
|     | Exterior Interface .....  | - 2 -  |
|     | R503 Info .....   | - 2 -  |
|     | R503-M22 Info .....   | - 2 -  |
|     | Serial Communication .....  | - 3 -  |
|     | Hardware Connection .....   | - 3 -  |
|     | Serial communication protocol .....                                 | - 3 -  |
|     | Power-on delay time .....   | - 4 -  |
|     | Power Supply Requirements .....                                     | - 4 -  |
|     | Ripple noise .....  | - 4 -  |
| III | System Resources .....  | - 5 -  |
|     | Notepad .....   | - 5 -  |
|     | Buffer .....  | - 5 -  |
|     | Fingerprint Library .....   | - 5 -  |
|     | System Configuration Parameters .....                               | - 5 -  |
|     | Baud rate control (Parameter Number: 4) .....                       | - 6 -  |
|     | Security Level (Parameter Number: 5) .....                          | - 6 -  |
|     | Data package length (Parameter Number: 6) .....                     | - 6 -  |
|     | System status register .....  | - 6 -  |
|     | Module password .....   | - 6 -  |
|     | Module address .....  | - 6 -  |
|     | Random number generator .....                                       | - 7 -  |
|     | Features and templates .....  | - 7 -  |
| IV  | Communication Protocol .....  | - 8 -  |
|     | Data package format .....   | - 8 -  |
|     | Instruction Table .....   | - 9 -  |
|     | Check and acknowledgement of data package .....                     | - 9 -  |
| V   | Module Instruction System .....                                     | - 11 - |
|     | System-related instructions .....                                   | - 11 - |
|     | Verify password   VfyPwd .....                                      | - 11 - |
|     | Set password     SetPwd .....                                       | - 11 - |
|     | Set Module address               SetAdder .....                     | - 12 - |
|     | Set module system's basic parameter   SetSysPara .....              | - 12 - |
|     | Read system Parameter               ReadSysPara .....               | - 13 - |
|     | Read valid template number   TemplateNum .....                      | - 13 - |
|     | Read fingerprint template index table   ReadIndexTable (0x1F) ..... | - 14 - |
|     | Get the algorithm library version   GetAlgVer (0x39) .....          | - 15 - |
|     | Get the firmware version   GetFwVer (0x3A) .....                    | - 15 - |
|     | Read product information   ReadProdInfo (0x3C) .....                | - 16 - |
|     | Fingerprint-processing instructions .....                           | - 17 - |
|     | To collect finger image   GetImg .....                              | - 17 - |
|     | To upload image   UpImage .....                                     | - 17 - |

|  |                             |        |
|--|-----------------------------|--------|
| To download the image  | DownImage .....             | - 18 - |
| To generate character file from image                                      | GenChar .....               | - 19 - |
| To generate template   | RegModel .....              | - 19 - |
| To upload template   | UpChar .....                | - 20 - |
| To download template   | DownChar .....              | - 20 - |
| To store template  | Store .....                 | - 21 - |
| To read template from Flash library  | LoadChar .....              | - 22 - |
| To delete template   | DeletChar .....             | - 22 - |
| To empty finger library  | Empty .....                 | - 23 - |
| To carry out precise matching of two finger templates                      | Match .....                 | - 23 - |
| To search finger library   | Search .....                | - 24 - |
| Fingerprint image collection extension command                             | GetImageEx(0x28) .....      | - 24 - |
| Cancel instruction   | Cancel(0x30) .....          | - 25 - |
| HandShake  | HandShake (0x40) .....      | - 26 - |
| CheckSensor  | CheckSensor (0x36) .....    | - 26 - |
| Soft reset   | SoftRst (0x3D) .....        | - 27 - |
| Aura control   | AuraLedConfig (0 x35) ..... | - 27 - |
| Automatic registration template  | AutoEnroll (0 x31) .....    | - 28 - |
| Automatic fingerprint verification   | AutoIdentify (0 x32) .....  | - 31 - |
| Other instructions .....   |                             | - 32 - |
| To generate a random code  | GetRandomCode .....         | - 32 - |
| To read information page   | ReadInfPage .....           | - 33 - |
| To write note pad  | WriteNotepad .....          | - 33 - |
| To read note pad   | ReadNotepad .....           | - 34 - |
| VI Operation Process .....   |                             | - 35 - |
| 6.1 Basic communication flow .....   |                             | - 35 - |
| 6.1.1 Process of the UART command package .....                            |                             | - 35 - |
| 6.1.2 UART Packet Sending Process .....                                    |                             | - 36 - |
| 6.1.3 UART packet receiving process .....                                  |                             | - 37 - |
| 6.2 General instruction communication flow .....                           |                             | - 38 - |
| 6.2.1 General instruction register fingerprint process .....               |                             | - 38 - |
| 6.2.2 General instruction verity fingerprint process .....                 |                             | - 39 - |
| 6.2.3 Read a specified template upload to Flash Fingerprint Database ..... |                             | - 40 - |
| 6.3 Automatic Register Fingerprint .....                                   |                             | - 41 - |
| 6.4 Automatic Fingerprint Verification(Search) .....                       |                             | - 42 - |
| 6.5 Low power standby .....  |                             | - 43 - |
| VII Reference Circuit .....  |                             | - 44 - |

# I Introduction

|  |   |  |                                     |
|--|---|--|-------------------------------------|
| <b>Power</b>                                     | DC 3.3V   | <b>Interface</b>                             | UART(3.3V TTL logical level)        |
| <b>Working current (Fingerprint acquisition)</b> | 20mA  | <b>Matching Mode</b><br><b>Matching Time</b> | 1:1 and 1:N<br>1:N<10ms/Fingerprint |
| <b>Standby current (finger detection)</b>        | Typical touch standby voltage: 3.3V<br>Average current: 2uA | <b>Characteristic value size</b>             | 512 bytes                           |
| <b>Baud rate</b>                                 | (9600*N)bps,<br>N=1~6 (default N=6)                         | <b>Template size</b>                         | 1536 bytes                          |
| <b>Image acquiring time</b>                      | <0.2s   | <b>Image resolution</b>                      | 508dpi                              |
| <b>Sensing Array</b>                             | 192*192 pixel   | <b>Detection Area</b>                        | Diameter 15mm                       |
| <b>Storage capacity</b>                          | 200   | <b>Security level</b>                        | 3 (1, 2, 3, 4, 5(highest))          |
| <b>FAR</b>                                       | <0.001%   | <b>FRR</b>                                   | <1%                                 |
| <b>Generate feature point time</b>               | < 500ms   | <b>Starting time</b>                         | ≤50ms                               |
| <b>Working environment</b>                       | Temp: -20℃ - +60℃   | <b>Storage environment</b>                   | Temp: -40℃ - +75℃                   |
|  | RH: 10%-85%   |  | RH: <85%                            |

## Operation Principle

Fingerprint processing includes two parts: fingerprint enrollment and fingerprint matching (the matching can be 1:1 or 1:N).

When enrolling, user needs to enter the finger two times. The system will process the two time finger images, generate a template of the finger based on processing results and store the template. When matching, user enters the finger through optical sensor and system will generate a template of the finger and compare it with templates of the finger library. For 1:1 matching, system will compare the live finger with specific template designated in the Module; for 1:N matching, or searching, system will search the whole finger library for the matching finger. In both circumstances, system will return the matching result, success or failure.

## II Hardware Interface

### Exterior Interface

#### R503 Info

Connector: SH1.0--6P Thread:M25

Product external diameter: 28mm Inner diameter:25mm Height:19mm

Enclosure material: Zinc Alloy

(Standard height is 19mm, also have 15mm and 32mm height,or need black aluminium alloy enclosure, pls contact sales, support customized)




#### R503-M22 Info

Connector: SH1.0--6P Thread:M22


Enclosure material: Zinc Alloy

Product external diameter: 25mm Inner diameter:22mm Height:15mm



## Serial Communication

Connector: SH1.0--6P

| Pin | Name         | Description   | Pic   |
|-----|--------------|---|---|
| 1   | Power Supply | DC3.3V  |  |
| 2   | GND          | Signal ground.<br>Connected to power ground.                                  |   |
| 3   | TXD          | Data output. TTL logical level  |   |
| 4   | RXD          | Data input. TTL logical level   |   |
| 5   | WAKEUP       | Finger Detection Signal. Standby-high level,<br>have finger-output low level. |   |
| 6   | 3.3VT        | Touch induction power supply, DC3—5V  |   |
|     |              |   | <p>Note:</p> <p>The line order has nothing to do with color.</p>                    |

## Hardware Connection

The RX of the module is connected with the TX of the upper computer, and the TX of the module is connected with the RX of the upper computer. The IRQ signal can be connected with the middle fracture or IO port of the upper computer.

To reduce the system standby power consumption, when the upper computer needs to use the fingerprint module, then power on the main power supply of the fingerprint module. At this time, the fingerprint module is powered on, and complete the corresponding instructions sent by the upper computer. When the upper computer does not need to use the fingerprint module, disconnect the fingerprint module from the main power supply.

When the upper computer is in standby mode, in order to keep the finger touch detection, the touch power supply needs to be powered all the time. The working voltage of the touch power supply is 3V~5V, and the average current of the touch power supply is about 2uA. When there is no finger touch, the default touch sensing signal outputs high level; When a finger touches, the default touch sensing signal outputs low level. After detecting the touch sensing signal, the upper computer supplies power to the fingerprint module and the fingerprint module starts to work.


The maximum response time of the touch function is about 120mS @ $V_t=3.3V$ . When the module is not touched, the recalibration period is about 4.0sec; the touch signal output is CMOS output, and the output voltage is roughly the same as the input voltage.

## Serial communication protocol

The mode is semiduplex asynchronism serial communication. And the default baud rate is 57600bps. User may set the baud rate in 9600~115200bps.

Transferring frame format is 10 bit: the low-level starting bit, 8-bit data with the LSB first, and an ending bit. There is no check bit.





## Power-on delay time

At power on, it takes about 50ms for initialization. During this period, the module can't accept commands for upper computer. After completing the initialization, the module will immediately send a byte (0x55) to the upper computer, indicating that the module can work normally and receive instructions from the upper computer.

## Power Supply Requirements

The power supply is DC +3.3V. The power input is allowed only after the R503/R503-M22 is properly connected.

Electrical components of the R503/R503-M22 may be damaged if you insert or remove the cable (with the electric plug) when the cable is live. Ensure that the power supply is switched off when you insert or remove the cable.

The R503/R503-M22 may not work properly due to poor power connections, short power off/on intervals, or excessive voltage drop pulses. So pls keep the power is stable. After the power is turned off, the power must be turned on at least two seconds later.

## Ripple noise

Since the power input of R503/R503-M22 is directly supplied to the image sensor and decoding chip.

To ensure stable operation, pls use low ripple noise power input.

It is recommended that the ripple noise not exceed 50mV (peak-to-peak).

## III System Resources

To address demands of different customer, Module system provides abundant resources at user's use.

### Notepad

The system sets aside a 512-bytes memory (16 pages\* 32 bytes) for user's notepad, where data requiring power-off protection can be stored. The host can access the page by instructions of PS\_WriteNotepad and PS\_Read Notepad.

Note: when write on one page of the pad, the entire 32 bytes will be written in wholly covering the original contents.

The user can run the module address or random number command to configure the unique matching between the module and the system. That is, the system identifies only the unique module. If a module of the same type is replaced, the system cannot access the system.

### Buffer

The module RAM resources are as follows:

An ImageBuffer: ImageBuffer

6 feature buffers: CharBuffer[1:6]

All buffer contents are not saved without power.

The user can read and write any buffer by instruction. CharBuffer can be used to store normal feature files or store template feature files.

When uploading or downloading images through the UART port, only the high four bits of pixel bytes are used to speed up the transmission, that is, use gray level 16, two pixels are combined into one byte. (The high four bits are a pixel, the low four bits are a pixel in the next adjacent column of the same row, that is, two pixels are combined into one byte and transmitted)

Since the image has 16 gray levels, when it is uploaded to PC for display (corresponding to BMP format), the gray level should be extended (256 gray levels, that is, 8bit bitmap format).

### Fingerprint Library

System sets aside a certain space within Flash for fingerprint template storage, that's fingerprint library. The contents of the fingerprint database are protected by power-off, and the serial number of the fingerprint database starts from 0.

Capacity of the library changes with the capacity of Flash, system will recognize the latter automatically. Fingerprint template's storage in Flash is in sequential order. Assume the fingerprint capacity N, then the serial number of template in library is 0, 1, 2, 3 ... N. User can only access library by template number.

### System Configuration Parameters

The system allows the user to individually modify a specified parameter value (by parameter serial number) by command. Refer to *SetSysPara*. After the upper computer sets the system parameter instructions, the system must be powered on again so that the module can work according to the new

## Baud rate control (Parameter Number: 4)

The Parameter controls the UART communication speed of the Module. Its value is an integer N, N= [1/2/4/6/12]. Corresponding baud rate is 9600\*N bps.

## Security Level (Parameter Number: 5)

The Parameter controls the matching threshold value of fingerprint searching and matching. Security level is divided into 5 grades, and corresponding value is 1, 2, 3, 4, 5. At level 1, FAR is the highest and FRR is the lowest; however at level 5, FAR is the lowest and FRR is the highest.

## Data package length (Parameter Number: 6)

The parameter decides the max length of the transferring data package when communicating with upper computer. Its value is 0, 1, 2, 3, corresponding to 32 bytes, 64 bytes, **128 bytes**, 256 bytes respectively.

## System status register

System status register indicates the current operation status of the Module. Its length is 1 word, and can be read via instruction *ReadSysPara*. Definition of the register is as follows:

| Bit Num     | 15       | 4 | 3          | 2   | 1    | 0    |
|-------------|----------|---|------------|-----|------|------|
| Description | Reserved |   | ImgBufStat | PWD | Pass | Busy |

Note:

Busy: 1 bit. 1: system is executing commands; 0: system is free;

Pass: 1 bit. 1: find the matching finger; 0: wrong finger;

PWD: 1 bit. 1: Verified device's handshaking password.

ImgBufStat: 1 bit. 1: image buffer contains valid image.

## Module password

The default password of the module is 0x00000000. If the default password is modified, after the module is powered on, the first instruction of the upper computer to communicate with the module must be verify password. Only after the password verification is passed, the module will enter the normal working state and receive other instructions.

The new modified password is stored in Flash and remains at power off. (the modified password cannot be obtained through the communication instruction. If forgotten by mistake, the module cannot communicate, please use with caution)

Refer to instruction *SetPwd* and *VfyPwd*.

## Module address

Each module has an identifying address. When communicating with upper computer, each instruction/data is transferred in data package form, which contains the address item. Module system only responds to data package whose address item value is the same with its identifying address.



The address length is 4 bytes, and its default factory value is 0xFFFFFFFF. User may modify the address via instruction *SetAddr*. The new modified address remains at power off.

## Random number generator

Module integrates a hardware 32-bit random number generator (RNG) (without seed). Via instruction *GetRandomCode*, system will generate a random number and upload it.

## Features and templates

The chip has one image buffer and six feature file buffers, all buffer contents are not saved after power failure.

A template can be composed of 2-6 feature files. The more feature files in the synthesis template, the better the quality of the fingerprint template.

It is recommended to take at least four templates to synthesize features.

## IV Communication Protocol

The protocol defines the data exchanging format when R503/R503-M22 series communicates with upper computer. The protocol and instruction sets applies for both UART communication mode.

Baud rate 57600, data bit 8, stop bit 1, parity bit none.

### Data package format

When communicating, the transferring and receiving of command/data/result are all wrapped in data package format. For multi-bytes, the high byte precedes the low byte (for example, a 2 bytes 00 06 indicates 0006, not 0600).

#### Data package format

| Header | Adder | Package identifier | Package length | Package content<br>(instruction/data/Parameter ) | Checksum |
|--------|-------|--------------------|----------------|--|----------|
|--------|-------|--------------------|----------------|--|----------|

#### Definition of Data package

| Name               | Symbol | Length  | Description  |
|--------------------|--------|---------|--|
| Header             | Start  | 2 bytes | Fixed value of 0xEF01; High byte transferred first.  |
| Adder              | ADDER  | 4 bytes | Default value is 0xFFFFFFFF, which can be modified by command. High byte transferred first and at wrong adder value, module will reject to transfer.   |
| Package identifier | PID    | 1 byte  | 01H Command packet;  |
|                    |        |         | 02H Data packet; Data packet shall not appear alone in executing process, must follow command packet or acknowledge packet.  |
|                    |        |         | 07H Acknowledge packet;  |
|                    |        |         | 08H End of Data packet.  |
| Package length     | LENGTH | 2 bytes | Refers to the length of package content (command packets and data packets) plus the length of Checksum( 2 bytes). Unit is byte. Max length is 256 bytes. And high byte is transferred first. |
| Package contents   | DATA   | —       | It can be commands, data, command' s parameters, acknowledge result, etc. (fingerprint character value, template are all deemed as data);  |
| Checksum           | SUM    | 2 bytes | The arithmetic sum of package identifier, package length and all package contents. Overflowing bits are omitted. high byte is transferred first.   |

## Instruction Table

| Code | Identifier  | Description                                      | Code | Identifier     | Description                                    |
|------|-------------|--|------|----------------|--|
| 01H  | GenImg      | Collect finger image                             | 12H  | SetPwd         | To set password                                |
| 02H  | Genchar     | To generate character file from image            | 13H  | VfyPwd         | To verify password                             |
| 03H  | Match       | Carry out precise matching of two templates;     | 14H  | GetRandomCode  | to get random code                             |
| 04H  | Search      | Search the finger library                        | 15H  | SetAdder       | To set device address                          |
| 05H  | RegModel    | To combine character files and generate template | 16H  | ReadInfPage    | Read information page                          |
| 06H  | Store       | To store template;                               | 18H  | WriteNotepad   | to write note pad                              |
| 07H  | LoadChar    | to read/load template                            | 19H  | ReadNotepad    | To read note pad                               |
| 08H  | UpChar      | to upload template                               | 1DH  | TempleteNum    | To read finger template numbers                |
| 09H  | DownChar    | to download template                             | 1FH  | ReadIndexTable | Read-fingerprint template index table          |
| 0AH  | UpImage     | To upload image                                  | 0x28 | GetImageEx     | Fingerprint image collection extension command |
| 0BH  | DownImage   | To download image                                | 0x30 | Cancel         | Cancel instruction                             |
| 0CH  | DeletChar   | to delete templates                              | 0x40 | HandShake      | HandShake                                      |
| 0DH  | Empty       | to empty the library                             | 0x36 | Check Sensor   | CheckSensor                                    |
| 0EH  | SetSysPara  | To set system Parameter                          | 0x39 | GetAlgVer      | Get the algorithm library version              |
| 0FH  | ReadSysPara | To read system Parameter                         | 0x3C | ReadProdInfo   | Read product information                       |
| 0x3A | GetFwVer    | Get the firmware version                         | 0x35 | Aura control   | AuraLedConfig                                  |
| 0x3D | SoftRst     | Soft reset                                       | 0x32 | AutoIdentify   | Automatic fingerprint verification             |
| 0x31 | AutoEnroll  | Automatic registration template                  |      |                |  |

## Check and acknowledgement of data package

**Note: Commands shall only be sent from upper computer to the Module, and the Module acknowledges the commands.**

Upon receipt of commands, Module will report the commands execution status and results to upper computer through acknowledge packet. Acknowledge packet has parameters and may also have following data packet. Upper computer can't ascertain Module's package receiving status or command execution results unless through acknowledge packet sent from Module. Acknowledge packet includes 1 byte confirmation code and maybe also the returned parameter.

*Confirmation code's definition is :*

00h: command execution complete;

01h: error when receiving data package;

02h: no finger on the sensor;  
03h: fail to enroll the finger;  
06h: fail to generate character file due to the over-disorderly fingerprint image;  
07h: fail to generate character file due to lackness of character point or over-smallness of fingerprint image  
08h: finger doesn't match;  
09h: fail to find the matching finger;  
0Ah: fail to combine the character files;  
0Bh: addressing PageID is beyond the finger library;  
0Ch: error when reading template from library or the template is invalid;  
0Dh: error when uploading template;  
0Eh: Module can't receive the following data packages.  
0Fh: error when uploading image;  
10h: fail to delete the template;  
11h: fail to clear finger library;  
13h: wrong password!  
15h: fail to generate the image for the lackness of valid primary image;  
18h: error when writing flash;  
19h: No definition error;  
20h: the address code is incorrect;  
21h: password must be verified;  
22h: fingerprint template is empty;  
24h: fingerprint library is empty;  
26h: timeout  
27h: fingerprints already exist;  
29h: sensor hardware error;  
1Ah: invalid register number;  
1Bh: incorrect configuration of register;  
1Ch: wrong notepad page number;  
1Dh: fail to operate the communication port;  
1Fh: fingerprint library is full;  
FCh: unsupported command;  
FDh: hardware error;  
FEh: command execution failure;  
others: system reserved;

# V Module Instruction System

## System-related instructions

### Verify password VfyPwd

Description: Verify Module's handshaking password.

Input Parameter: PassWord (4 bytes)

Return Parameter: Confirmation code (1 byte)

Instruction code: 13H

Command (or instruction) package format:

|         |                |                    |                |                  |          |          |
|---------|----------------|--------------------|----------------|------------------|----------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 4 bytes  | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Password | Checksum |
| 0xEF01  | xxxx           | 01H                | 0007H          | 13H              | PassWord | sum      |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package Length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code = 00H: Correct password;

Confirmation code = 01H: error when receiving package;

Confirmation code = 13H: Wrong password;

### Set password SetPwd

Description: Set Module's handshaking password.

Input Parameter: PassWord (4 bytes)

Return Parameter: Confirmation code (1 byte)

Instruction code: 12H

Command (or instruction) package format:

|         |                |                    |                |                  |          |          |
|---------|----------------|--------------------|----------------|------------------|----------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 4 bytes  | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Password | Checksum |
| 0xEF01  | xxxx           | 01H                | 0007H          | 12H              | PassWord | sum      |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package Length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code=00H: password setting complete;

Confirmation code=01H: error when receiving package;

Confirmation code=21H: have to verify password

Confirmation code=18H: error when write FLASH



## Set Module address SetAddr

Description: Set Module address.

Input Parameter: Addr

Return Parameter: Confirmation code (1 byte)

Instruction code: 15H

Command (or instruction) package format:

|         |                            |                       |                   |                     |                       |          |
|---------|----------------------------|-----------------------|-------------------|---------------------|-----------------------|----------|
| 2 bytes | 4bytes                     | 1 byte                | 2 bytes           | 1 byte              | 4 bytes               | 2 bytes  |
| Header  | Original<br>Module address | Package<br>identifier | Package<br>length | Instruction<br>code | New Module<br>address | Checksum |
| 0xEF01  | xxxx                       | 01H                   | 0007H             | 15H                 | Addr                  | sum      |

Acknowledge package format:

|         |                       |                       |                   |                      |          |
|---------|-----------------------|-----------------------|-------------------|----------------------|----------|
| 2 bytes | 4bytes                | 1 byte                | 2 bytes           | 1 byte               | 2 bytes  |
| Header  | New Module<br>address | Package<br>identifier | Package<br>length | Confirmation<br>code | Checksum |
| 0xEF01  | xxxx                  | 07H                   | 0003H             | xxH                  | Sum      |

Note: Confirmation code=00H: address setting complete;

Confirmation code=01H: error when receiving package;

Confirmation code=18H: error when write FLASH

## Set module system's basic parameter SetSysPara

Description: Operation parameter settings.

Input Parameter: Parameter number+Contents

Return Parameter: Confirmation code (1 byte)

Instruction code: 0eH

Command (or instruction) package format:

|         |                   |                       |                   |                     |                     |          |          |
|---------|-------------------|-----------------------|-------------------|---------------------|---------------------|----------|----------|
| 2 bytes | 4bytes            | 1 byte                | 2 bytes           | 1 byte              | 1byte               | 1byte    | 2 bytes  |
| Header  | Module<br>address | Package<br>identifier | Package<br>length | Instruction<br>code | Parameter<br>number | Contents | Checksum |
| 0xEF01  | Xxxx              | 01H                   | 0005H             | 0eH                 | 4/5/6               | xx       | sum      |

Acknowledge package format:

|         |                   |                       |                   |                      |          |
|---------|-------------------|-----------------------|-------------------|----------------------|----------|
| 2 bytes | 4bytes            | 1 byte                | 2 bytes           | 1 byte               | 2 bytes  |
| Header  | Module<br>address | Package<br>identifier | Package<br>length | Confirmation<br>code | Checksum |
| 0xEF01  | Xxxx              | 07H                   | 0003H             | xxH                  | Sum      |

Note: Confirmation code=00H: parameter setting complete;

Confirmation code=01H: error when receiving package;

Confirmation code=1aH: wrong register number;

Confirmation code=18H: error when write FLASH

| Name                  | Parameter number | Content   |
|-----------------------|------------------|---|
| Baud rate             | 4                | Data range:1, 2/4/6/12, indicates that baud rate is 9600 * N bps                          |
| Security level        | 5                | Data range: 1, 2, 3, 4, 5   |
| Packet content length | 6                | Data range: 0, 1, 2, 3 the corresponding lengths (bytes) are as follows: 32, 64, 128, 256 |

## Read system Parameter      ReadSysPara

Description: Read Module's status register and system basic configuration parameters;

Input Parameter: none

Return Parameter: Confirmation code (1 byte) + basic parameter (16bytes)

Instruction code: 0fH

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | Xxxx           | 01H                | 0003H          | 0fH              | 0013H    |

Acknowledge package format:

|         |                |                    |                |                   |                      |          |
|---------|----------------|--------------------|----------------|-------------------|----------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 16 bytes             | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Basic parameter list | Checksum |
| 0xEF01  | xxxx           | 07H                | 0013H          | xxH               | See following table  | sum      |

Note: Confirmation code=00H: read complete;

Confirmation code=01H: error when receiving package;

Confirmation code=18H: error when write FLASH

| Name                   | Description                        | Offset (word) | Size (word) |
|------------------------|------------------------------------|---------------|-------------|
| Status register        | Contents of system status register | 0             | 2           |
| System identifier code | Fixed value: 0x0000                | 1             | 2           |
| Finger library size    | Finger library size                | 2             | 2           |
| Security level         | Security level (1, 2, 3, 4, 5)     | 3             | 2           |
| Device address         | 32-bit device address              | 4             | 4           |
| Data packet size       | Size code (0, 1, 2, 3)             | 6             | 2           |
| Baud settings          | N (baud = 9600*N bps)              | 7             | 2           |

## Read valid template number      TemplateNum

Description: read the current valid template number of the Module

Input Parameter: none

Return Parameter: Confirmation code (1 byte), template number:N

Instruction code: 1dH

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 01H                | 0003H          | 1dH              | 0021H    |

Acknowledge package format:

|         |                |                    |                |                   |                 |          |
|---------|----------------|--------------------|----------------|-------------------|-----------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes         | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Template number | Checksum |
| 0xEF01  | xxxx           | 07H                | 0005H          | xxH               | Num             | sum      |

Note: Confirmation code=0x00: read success;

Confirmation code=0x01: error when receiving package;

## Read fingerprint template index table

## ReadIndexTable (0x1F)

Description: Read the fingerprint template index table of the module, read the index table of the fingerprint template up to 256 at a time (32 bytes)

Input Parameter: Index page

Return Parameter: Confirmation code+Fingerprint template index table

Instruction code: 0x1F

Command (or instruction) package format:

|         |                |                    |                |                  |            |          |
|---------|----------------|--------------------|----------------|------------------|------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte     | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Index page | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0004         | 0x1F             | 0/1/2/3    | Sum      |

Index tables are read per page, 256 templates per page

Index page 0 means to read 0 ~ 255 fingerprint template index table

Index page 1 means to read 256 ~ 511 fingerprint template index table

Index page 2 means to read 512 ~ 767 fingerprint template index table

Index page 3 means to read 768 ~ 1023 fingerprint template index table

Acknowledge package format:

|         |                |                    |                |                   |                     |           |
|---------|----------------|--------------------|----------------|-------------------|---------------------|-----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 32 bytes            | 2 bytes   |
| Header  | Module address | Package identifier | Package length | Confirmation code | Index page          | Check-sum |
| 0xEF01  | xxxx           | 0x07               | 0x0023         | X                 | See the table below | sum       |

Note: Confirmation code=0x00: read complete;

Confirmation code=0x01: error when receiving package;

Index table structure: every 8 bits is a group, and each group is output starting from the high position.

| transport order | The output is sequential from low byte to high byte, and each byte starts at a high byte. |     |     |     |     |     |     |     |     |
|-----------------|---|-----|-----|-----|-----|-----|-----|-----|-----|
| T[0]            | Template number   | 7   | 6   | 5   | 4   | 3   | 2   | 1   | 0   |
|                 | Index table data  | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 |
| T[1]            | Template number   | 15  | 14  | 13  | 12  | 11  | 10  | 9   | 8   |

|       |                  |     |     |     |     |     |     |     |     |
|-------|------------------|-----|-----|-----|-----|-----|-----|-----|-----|
|       | Index table data | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 |
| ...   | ...              |     |     |     |     |     |     |     |     |
| T[31] | Template number  | 255 | 254 | 253 | 252 | 251 | 250 | 249 | 248 |
|       | Index table data | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 | 0/1 |

Data "0" in the index table means that there is no valid template in the corresponding position;"1" means that there is a valid template in the corresponding position.

## Get the algorithm library version      GetAlgVer (0x39)

Description: Get the algorithm library version

Input Parameter: none

Return Parameter: Confirmation code+AlgVer(algorithm library version string)

Instruction code: 0x39

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x39             | 003DH    |

Acknowledge package format:

|         |                |                    |                |                   |               |          |
|---------|----------------|--------------------|----------------|-------------------|---------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 32 bytes      | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Random number | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0023         | X                 | AlgVer        | sum      |

Note 1: Confirmation code=0x00: success;

Confirmation code=0x01: error when receiving package;

## Get the firmware version      GetFwVer (0x3A)

Description: Get the firmware version

Input Parameter: none

Return Parameter: Confirmation code+FwVer(Firmware version string)

Instruction code: 0x3A

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x3A             | 003EH    |

Acknowledge package format:

|         |                |                    |                |                   |               |          |
|---------|----------------|--------------------|----------------|-------------------|---------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 32 bytes      | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Random number | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0023         | X                 | FwVer         | sum      |

Note 1: Confirmation code=0x00: success;

Confirmation code=0x01: error when receiving package;

## Read product information      ReadProdInfo (0x3C)

Description: Read product information

Input Parameter: none

Return Parameter: Confirmation code+ProdInfo(product information)

Instruction code: 0x3C

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x3C             | 0040H    |

Acknowledge package format:

|         |                |                    |                |                   |                     |          |
|---------|----------------|--------------------|----------------|-------------------|---------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 50 bytes            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Product information | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0031         | X                 | ProdInfo            | sum      |

Note 1: Confirmation code=0x00: success;

Confirmation code=0x01: error when receiving package;

Product information: store in the following order. For Numbers, the high byte comes first. For a string, the insufficient part is 0x00.

| Code             | Bytes | Meaning   |
|------------------|-------|---|
| PARAM_FPM_MODEL  | 16    | module type, ASCII  |
| PARAM_BN         | 4     | Module batch number, ASCII  |
| PARAM_SN         | 8     | Module serial number, ASCII   |
| PARAM_HW_VER     | 2     | For the hardware version, the first byte represents the main version and the second byte represents the sub-version |
| PARAM_FPS_MODEL  | 8     | Sensor type, ASCII  |
| PARAM_FPS_WIDTH  | 2     | Sensor image width  |
| PARAM_FPS_HEIGHT | 2     | Sensor image height   |
| PARAM_TMPL_SIZE  | 2     | Template size   |
| PARAM_TMPL_TOTAL | 2     | Fingerprint database size   |
| Other            | 4     | System Reserved   |

## Fingerprint-processing instructions

### To collect finger image      **GetImg**

Description: detecting finger and store the detected finger image in ImageBuffer while returning successfully confirmation code; If there is no finger, returned confirmation code would be “can’t detect finger”.

**The difference between GetImageEx and GetImage instruction:**

**GetImage:** When the image quality is poor, return confirmation code 0x00 (the image is successfully captured).

**GetImageEx:** When image quality is poor, return confirmation code 0x07 (image quality is too poor).

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 01H

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | Xxxx           | 01H                | 0003H          | 01H              | 0005H    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | Sum      |

Note: Confirmation code=00H: finger collection success;

Confirmation code=01H: error when receiving package;

Confirmation code=02H: can’t detect finger;

Confirmation code=03H: fail to collect finger;

### To upload image      **UpImage**

Description: to upload the image in Img\_Buffer to upper computer.

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 0aH

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | Xxxx           | 01H                | 0003H          | 0aH              | 000eH    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | sum      |

- Note 1: Confirmation code=00H: ready to transfer the following data packet;  
 Confirmation code=01H: error when receiving package;  
 Confirmation code=0fH: fail to transfer the following data packet;

- The upper computer sends the command packet, the module sends the acknowledge packet first, and then sends several data packet.
- Packet Bytes N is determined by Packet Length. The value is 128 Bytes before delivery.

Data package format:

| 2 bytes | 4bytes         | 1 byte   | 2 bytes        | N bytes         | 2 bytes  |
|---------|----------------|--|----------------|-----------------|----------|
| Header  | Module address | Package identifier                               | Package length | Package content | Checksum |
| 0xEF01  | xxxx           | 0x02- have following packet<br>0x08 - end packet | N+2            | Image data      | sum      |

## To download the image      DownImage

Description: to download image from upper computer to Img\_Buffer.

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 0bH

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | Xxxx           | 01H                | 0003H          | 0bH              | 000fH    |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | sum      |

- Note: 1: Confirmation code=00H: ready to transfer the following data packet;  
 Confirmation code=01H: error when receiving package;  
 Confirmation code=0eH: fail to transfer the following data packet;

- The upper computer sends the command packet, the module sends the acknowledge packet first, and then sends several data packet.

- Packet Bytes N is determined by Packet Length. The value is 128 Bytes before delivery.

Data package format:

| 2 bytes | 4bytes         | 1 byte   | 2 bytes        | N bytes         | 2 bytes  |
|---------|----------------|--|----------------|-----------------|----------|
| Header  | Module address | Package identifier                               | Package length | Package content | Checksum |
| 0xEF01  | xxxx           | 0x02- have following packet<br>0x08 - end packet | N+2            | Image data      | sum      |

## To generate character file from image      GenChar

Description: to generate character file from the original finger image in ImageBuffer

Input Parameter: BufferID (character file buffer number)

Return Parameter: Confirmation code (1 byte)

Instruction code: 02H

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|---------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Buffer number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0004H          | 02H              | CharBuffer ID | sum      |

**CharBufferID: Character buffer number, range 1-6.**

**The R300-A module requires a minimum of four and a maximum of six fingerprint features for the generate template.**

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | XxH               | sum      |

Note: Confirmation code=00H: generate character file complete;

Confirmation code=01H: error when receiving package;

Confirmation code=06H: fail to generate character file due to the over-disorderly fingerprint image;

Confirmation code=07H: fail to generate character file due to lackness of character point or over-smallness of fingerprint image;

Confirmation code=15H: fail to generate the image for the lackness of valid primary image;

## To generate template      RegModel

Description: To combine information of character files from CharBuffer1 and CharBuffer2 and generate a template which is stored back in both CharBuffer1 and CharBuffer2.

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 05H

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 01H                | 0003H          | 05H              | 0009H    |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |



|        |      |     |       |     |     |
|--------|------|-----|-------|-----|-----|
| 0xEF01 | xxxx | 07H | 0003H | xxH | sum |
|--------|------|-----|-------|-----|-----|

Note: Confirmation code=00H: operation success;

Confirmation code=01H: error when receiving package;

Confirmation code=0aH: fail to combine the character files. That's, the character files don't belong to one finger.

## To upload template UpChar

Description: Upload the data in the template buffer ModelBuffer to the upper computer.

Input Parameter: CharBufferID

Return Parameter: Confirmation code (1 byte)

Instruction code: 08H

Command (or instruction) package format:

|         |                |                    |                |                  |               |          |
|---------|----------------|--------------------|----------------|------------------|---------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Buffer number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0004H          | 08H              | CharBuffer ID | sum      |

**Note: This command don't need to use the CharBufferID, so the CharBufferID can be any value between 1 and 6.**

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0dH: error when uploading template;

Confirmation code=0fH: can not receive the following data packet

4. The upper computer sends the command packet, the module sends the acknowledge packet first, and then sends several data packet.

5. Packet Bytes N is determined by Packet Length. The value is 128 Bytes before delivery.

6: The instruction doesn't affect buffer contents.

Data package format:

|         |                |  |                |                 |          |
|---------|----------------|--|----------------|-----------------|----------|
| 2 bytes | 4bytes         | 1 byte   | 2 bytes        | N bytes         | 2 bytes  |
| Header  | Module address | Package identifier                               | Package length | Package content | Checksum |
| 0xEF01  | xxxx           | 0x02- have following packet<br>0x08 - end packet | N+2            | Template data   | sum      |

## To download template DownChar

Description: upper computer download template to module buffer

Input Parameter: CharBufferID (Buffer number)

Return Parameter: Confirmation code (1 byte)

Instruction code: 09H

Command (or instruction) package format:

|         |                |                    |                |                  |               |          |
|---------|----------------|--------------------|----------------|------------------|---------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Buffer number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0004H          | 09H              | CharBufferID  | sum      |

**Note: This command don't need to use the CharBufferID, so the CharBufferID can be any value between 1 and 6.**

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0eH: can not receive the following data packet

Data package format:

|         |                |  |                |                 |          |
|---------|----------------|--|----------------|-----------------|----------|
| 2 bytes | 4bytes         | 1 byte   | 2 bytes        | N bytes         | 2 bytes  |
| Header  | Module address | Package identifier                               | Package length | Package content | Checksum |
| 0xEF01  | xxxx           | 0x02- have following packet<br>0x08 - end packet | N+2            | Template data   | sum      |

Note 2. The upper computer sends the command packet, the module sends the acknowledge packet first, and then sends several data packet.

3.Packet Bytes N is determined by Packet Length. The value is 128 Bytes before delivery.

4. The instruction doesn't affect buffer contents.

## To store template Store

Description: to store the template of specified buffer (Buffer1/Buffer2) at the designated location of Flash library.

Input Parameter: CharBufferID, ModelID

Return Parameter: Confirmation code (1 byte)

Instruction code: 06H

Command (or instruction) package format:

|         |                |                    |                |                  |               |                 |          |
|---------|----------------|--------------------|----------------|------------------|---------------|-----------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes         | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | buffer number | Location number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0006H          | 06H              | CharBuffer ID | ModelID         | sum      |

**Note: CharBufferID is filled with 0x01**

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code=00H: storage success;

Confirmation code=01H: error when receiving package;

Confirmation code=0bH: addressing ModelID is beyond the finger library;

Confirmation code=18H: error when writing Flash.

## To read template from Flash library      LoadChar

Description: to load template at the specified location (PageID) of Flash library to template buffer CharBuffer1/CharBuffer2

Input Parameter: CharBufferID, ModelID

Return Parameter: Confirmation code (1 byte)

Instruction code: 07H

Command (or instruction) package format:

|         |                |                    |                |                  |               |             |          |
|---------|----------------|--------------------|----------------|------------------|---------------|-------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes     | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | buffer number | Page number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0006H          | 07H              | CharBuffer ID | ModelID     | sum      |

**Note:** CharBufferID is filled with 0x01

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | XxH               | sum      |

Note: Confirmation code=00H: load success;

Confirmation code=01H: error when receiving package;

Confirmation code=0cH: error when reading template from library or the readout template is invalid;

Confirmation code=0BH: addressing ModelID is beyond the finger library;

## To delete template      DeletChar

Description: to delete a segment (N) of templates of Flash library started from the specified location (or PageID);

Input Parameter: StartID + Num

Return Parameter: Confirmation code (1 byte)

Instruction code: 0cH

Command (or instruction) package format:

|         |        |         |         |             |         |           |          |
|---------|--------|---------|---------|-------------|---------|-----------|----------|
| 2 bytes | 4bytes | 1 byte  | 2 bytes | 1 byte      | 2 bytes | 2bytes    | 2 bytes  |
| Header  | Module | Package | Package | Instruction | Page    | number of | Checksum |

|        | address | identifier | length | code | number  | templates to be deleted |     |
|--------|---------|------------|--------|------|---------|-------------------------|-----|
| 0xEF01 | Xxxx    | 01H        | 0007H  | 0cH  | StartID | Num                     | sum |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code=00H: delete success;

Confirmation code=01H: error when receiving package;

Confirmation code=10H: failed to delete templates;

Confirmation code=18H: error when write FLASH

## To empty finger library Empty

Description: to delete all the templates in the Flash library

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 0dH

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | Xxxx           | 01H                | 0003H          | 0dH              | 0011H    |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code=00H: empty success;

Confirmation code=01H: error when receiving package;

Confirmation code=11H: fail to clear finger library;

Confirmation code=18H: error when write FLASH

## To carry out precise matching of two finger templates Match

Description: Compare the recently extracted character with the templates in the ModelBuffer, providing matching results.

Input Parameter: none

Return Parameter: Confirmation code (1 byte), matching score.

Instruction code: 03H

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |

|        |      |     |       |     |       |
|--------|------|-----|-------|-----|-------|
| 0xEF01 | Xxxx | 01H | 0003H | 03H | 0007H |
|--------|------|-----|-------|-----|-------|

Acknowledge package format:

|         |                |                    |                |                   |                |          |
|---------|----------------|--------------------|----------------|-------------------|----------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes        | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Matching score | Checksum |
| 0xEF01  | Xxxx           | 07H                | 0005H          | XxH               | MatchScore     | sum      |

Note 1: Confirmation code=00H: templates of the two buffers are matching!

Confirmation code=01H: error when receiving package;

Confirmation code=08H: templates of the two buffers aren't matching;

2: The instruction doesn't affect the contents of the buffers.

## To search finger library Search

Description: to search the whole finger library for the template that matches the one in CharBuffer1 or CharBuffer2. When found, PageID will be returned.

Input Parameter: CharBufferID + StartID + Num

Return Parameter: Confirmation code+ModelID(template number)+ MatchScore

Instruction code: 04H

Command (or instruction) package format:

|         |                |                    |                |                  |               |           |           |          |
|---------|----------------|--------------------|----------------|------------------|---------------|-----------|-----------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte        | 2 bytes   | 2 bytes   | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | buffer number | Parameter | Parameter | Checksum |
| 0xEF01  | xxxx           | 01H                | 0008H          | 04H              | CharBufferID  | StartID   | Num       | sum      |

**Note: CharBufferID is filled with 0x01**

Acknowledge package format:

|         |                |                    |                |                   |          |            |          |
|---------|----------------|--------------------|----------------|-------------------|----------|------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  | 2 bytes    | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Page     | Score      | Checksum |
| 0xEF01  | xxxx           | 07H                | 0007H          | xxH               | Model ID | MatchScore | sum      |

Note 1: Confirmation code=00H: found the matching finger;

Confirmation code=01H: error when receiving package;

Confirmation code=09H: No matching in the library (both the PageID and matching score are 0);

2: The instruction doesn't affect the contents of the buffers.

## Fingerprint image collection extension command GetImageEx(0x28)

Description: Detect the finger, record the fingerprint image and store it in ImageBuffer, return it and record the successful confirmation code;If no finger is detected, return no finger confirmation code(the module responds quickly to each instruction,therefore, for continuous detection, cycle processing is required, which can be limited to the number of cycles or the total time).

**Differences between GetImageEx and the GetImage:**

**GetImage:** return the confirmation code 0x00 when the image quality is too bad (image collection succeeded)

**GetImageEx:** return the confirmation code 0x07 when the image quality is too bad (poor collection quality)

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 0x28

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x28             | 002CH    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: read success

Confirmation code=0x01: error when receiving package;

Confirmation code=0x02: no fingers on the sensor;

Confirmation code=0x03: unsuccessful entry

Confirmation code=0x07: poor image quality;

## Cancel instruction

## Cancel(0x30)

Description: Cancel instruction

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 0x30

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x30             | 0034H    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: cancel setting successful

Confirmation code=other: cancel setting failed

## HandShake

## HandShake (0x40)

Description: Send handshake instructions to the module. If the module works normally, the confirmation code 0x00 will be returned. The upper computer can continue to send instructions to the module. If the confirmation code is other or no reply, it means that the device is abnormal.

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 0x40

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x40             | 0044H    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: the device is normal and can receive instructions;

Confirmation code=other: the device is abnormal.

In addition, after the module is powered on, 0x55 will be automatically sent as a handshake sign. After the single-chip microcomputer detects 0x55, it can immediately send commands to enter the working state.

## CheckSensor

## CheckSensor (0x36)

Description: Check whether the sensor is normal

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 0x36

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x36             | 003AH    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: the sensor is normal;

Confirmation code=0x29: the sensor is abnormal.

## Soft reset

## SoftRst (0x3D)

Description: Send soft reset instruction to the module. If the module works normally, return confirmation code 0x00, and then perform reset operation.

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 0x3D

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0003         | 0x3D             | 0041H    |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: success;

Confirmation code=other: device is abnormal

After module reset, 0x55 will be automatically sent as a handshake sign. After the single-chip microcomputer detects 0x55, it can immediately send commands to enter the working state.

## Aura control

## AuraLedConfig (0 x35)

Description: Aura LED control

Input Parameter: Control code:Ctrl; Speed; ColorIndex;Times

Return Parameter: Confirmation code

Instruction code: 0x35

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1 byte       | 1 byte | 1 byte      | 1 byte | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|--------------|--------|-------------|--------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Control code | Speed  | Color Index | Times  | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0007         | 0x35             | Ctrl         | Speed  | Color Index | Count  | sum      |

Control Code:

| Control code | 0x01            | 0x02           | 0x03            | 0x04             | 0x05               | 0x06                |
|--------------|-----------------|----------------|-----------------|------------------|--------------------|---------------------|
| Function     | breathing light | Flashing light | Light Always on | Light Always off | Light gradually on | Light gradually off |

Speed: 0x00-0xff, 256 gears, Minimum 5s cycle.

It is effective for breathing lamp and flashing lamp, Light gradually on, Light gradually off





ColorIndex:

|       |      |      |        |       |        |      |       |
|-------|------|------|--------|-------|--------|------|-------|
| Code  | 0x01 | 0x02 | 0x03   | 0x04  | 0x05   | 0x06 | 0x07  |
| Color | Red  | Blue | Purple | Green | Yellow | Cyan | White |

Number of cycles: 0- infinite, 1-255.

It is effective for with breathing light and flashing light.

Example of setting light: Cyan breathing light:

Send: EF 01 FF FF FF FF 01 00 07 35 01 50 06 00 00 94

Return: EF 01 FF FF FF FF 07 00 03 00 00 0A

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0003         | X                 | sum      |

Note 1: Confirmation code=0x00: success;

Confirmation code=0x01:error when receiving package;

## Automatic registration template

## AutoEnroll (0 x31)

When a fingerprint is recorded using an automatic registration template, the fingerprint image needs to be recorded six times for each fingerprint template. The blue light blinks when the fingerprint image is collected. The yellow light is on means the fingerprint image is collected successfully, the green light blinks means the fingerprint characteristic is generated successfully. If the finger is required to leave during image collection, the image will be collected again after the finger is lifted. During the process of waiting for the finger to leave, the white light flashes. After fingerprint images are collected for 6 times and features are generated successfully, features are synthesized and store fingerprint template. If the operation succeeds, the green light is on; if the operation fails, the red light is on. If the finger is away from the sensor for more than 10 seconds when in collecting the fingerprint image each time, it will automatically exits the automatic template registration process.

Input Parameter:ModelID- Fingerprint library location number

Config1: Whether to allow cover ID number

Config2: Whether to allow duplicate fingerprints

Config3: Whether the module return the status in the critical step

Config4: Whether to allow ask the finger to leave

Return Parameter:Confirmation code ModelID(Fingerprint library location number)

Instruction code: 0x31

Command (or instruction) package format:

|         |                |                    |                |                  |          |                   |                   |                |                    |          |
|---------|----------------|--------------------|----------------|------------------|----------|-------------------|-------------------|----------------|--------------------|----------|
| 2 bytes | 4 bytes        | 1 byte             | 2 bytes        | 1 byte           | 1 byte   | 1 byte            | 1 byte            | 1 byte         | 1 byte             | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Location | Whether Duplicate | Whether Duplicate | Whether return | Whether ask finger | Checksum |

|        |      |      |        |      |    |         |             |         |          |     |
|--------|------|------|--------|------|----|---------|-------------|---------|----------|-----|
|        |      |      |        |      | ID | e ID    | Fingerprint | status  | to leave |     |
| 0xEF01 | xxxx | 0x01 | 0x0008 | 0x31 | ID | Config1 | Config2     | Config3 | Config4  | sum |

**Model ID: Location ID : 0-0xC7**

**0xC8-0xFF is automatic filling(The ID number is assigned by the system.**

**The system will be starting from template 0 to searches the empty templates.)**

Whether to allow cover ID number: 0:Not allowed 1: Allow

Whether to allow register duplicate fingerprints: 0:Not allowed 1: Allow

Whether to return to the critical step status during registration: 0:Not allowed 1: Allow

Whether the finger is required to leave during the registration process in order to enter the next fingerprint image collection: 0: don't need to leave 1: have to leave

**Example of AutoEnroll:**

**Send: EF 01 FF FF FF FF 01 00 08 31 C8 00 01 01 01 01 05**

**Return: EF 01 FF FF FF FF 07 00 05 00 01 00 00 0D EF 01 FF FF FF FF 07 00 05 00 02 00 00 0E EF 01 FF FF FF FF 07 00 05 00 03 00 00 0F EF 01 FF FF FF FF 07 00 05 00 04 00 00 10 EF 01 FF FF FF FF 07 00 05 00 05 00 00 11 EF 01 FF FF FF FF 07 00 05 00 06 00 00 12 EF 01 FF FF FF FF 07 00 05 00 07 00 00 13 EF 01 FF FF FF FF 07 00 05 00 08 00 00 14 EF 01 FF FF FF FF 07 00 05 00 09 00 00 15 EF 01 FF FF FF FF 07 00 05 00 0A 00 00 16 EF 01 FF FF FF FF 07 00 05 00 0B 00 00 17 EF 01 FF FF FF FF 07 00 05 00 0C 00 00 18 EF 01 FF FF FF FF 07 00 05 00 0D 00 00 19 EF 01 FF FF FF FF 07 00 05 00 0E 00 00 1A EF 01 FF FF FF FF 07 00 05 00 0F 00 00 1B (Fingerprint ID)**

**Acknowledge package format:**

|         |                |                    |                |                   |             |             |          |
|---------|----------------|--------------------|----------------|-------------------|-------------|-------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 1 bytes     | 1 bytes     | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Parameter 1 | Parameter 2 | Checksum |
| 0xEF01  | xxxx           | 0x07               | 0x0005         | X                 | X           | X           | sum      |

**Parameter 1: Step Process:**

0x01: Collect image for the first time

0x02: Generate Feature for the first time

0x03: Collect image for the second time

0x04: Generate Feature for the second time

0x05: Collect image for the third time

0x06: Generate Feature for the third time

0x07: Collect image for the fourth time

0x08: Generate Feature for the fourth time

0x09: Collect image for the fifth time

0x0A: Generate Feature for the fifth time

0x0B: Collect image for the sixth time

0x0C: Generate Feature for the sixth time

0x0D: Repeat fingerprint check

0x0E: Merge feature

0x0F: Storage template

## Parameter 2: fingerprint ID

Specific Acknowledge package format:

| Header  | Module address | Package identifier | Package length | Confirmation code | Step   | Fingerprint ID | Check Sum | Note                                 |
|---------|----------------|--------------------|----------------|-------------------|--------|----------------|-----------|--------------------------------------|
| 2 Bytes | 4 Bytes        | 1 Byte             | 2 Bytes        | 1 Byte            | 1 Byte | 1 Byte         | 2 Bytes   |                                      |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x01   | 0x00           | Sum       | Collect image for the first time     |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x02   | 0x00           | Sum       | Generate Feature for the first time  |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x03   | 0x00           | Sum       | Collect image for the second time    |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x04   | 0x00           | Sum       | Generate Feature for the second time |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x05   | 0x00           | Sum       | Collect image for the third time     |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x06   | 0x00           | Sum       | Generate Feature for the third time  |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x07   | 0x00           | Sum       | Collect image for the fourth time    |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x08   | 0x00           | Sum       | Generate Feature for the fourth time |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x09   | 0x00           | Sum       | Collect image for the fifth time     |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0A   | 0x00           | Sum       | Generate Feature for the fifth time  |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0B   | 0x00           | Sum       | Collect image for the sixth time     |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0C   | 0x00           | Sum       | Generate Feature for the sixth time  |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0D   | 0x00           | Sum       | Repeat fingerprint check             |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0E   | 0x00           | Sum       | Merge feature                        |
| 0xEF01  | XXXX           | 0x07               | 0x0005         | X                 | 0x0F   | modelID        | Sum       | Storage template                     |

**If the status of return key step is set to 0 during registration, only returned the the last acknowledge packet.**

Confirmation code=0x00 set successfully

Confirmation code=0x01 set fails

Confirmation code=0x07 failed to generate a feature

Confirmation code=0x0a failed to merge templates

Confirmation code=0x0b the ID is out of range

Confirmation code=0x1f fingerprint library is full

Confirmation code=0x22 fingerprint template is empty

Confirmation code=0x26 times out

Confirmation code=0x27 fingerprint already exists

## Automatic fingerprint verification

## AutoIdentify (0 x32)

When the automatic fingerprint verification command is used to search and verify a fingerprint, the system automatically collects a fingerprint image and generates features, and compares the image with the fingerprint template in the fingerprint database. If the comparison is successful, the system returns the template ID number and the comparison score. If the comparison fails, the system returns the corresponding error code.

When obtaining the fingerprint image, the fingerprint head will light up with a white breathing light. After the image collection is successful, the yellow light will light up, and the green light will light up after the comparison is successful. If there is a fingerprint image collection error or no fingerprint search, the red light will be on to prompt.

If the system does not detect the finger for more than 10 seconds after sending the command or collecting the fingerprint image again after reporting an error, it will automatically exit the command.

Input Parameter:

SafeGrade (1-5 level)

StartID

Num -Number of searches

Config1 Whether the module returns to the status in key steps

Config2 Number of fingerprint search error

Return Parameter: Confirmation code ModelID MarchScore

Instruction code: 0x32

Command (or instruction) package format:

| 2 bytes | 4 bytes        | 1 byte             | 2 bytes        | 1 byte           | 1 byte         | 1 byte         | 1 byte             | 1 byte                  | 1 byte                             | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------------|----------------|--------------------|-------------------------|------------------------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Security Level | Start Position | Number of searches | Whether return key step | Number of fingerprint search error | Checksum |
| 0xEF01  | xxxx           | 0x01               | 0x0008         | 0x32             | Safe Grade     | Start ID       | num                | Config1                 | Config2                            | sum      |

Security level: 1-5

Starting position: 0-199

End position: 1-200

Return search steps: 0: not allowed 1: Allowed

Fingerprint search error times:

0-0xFF: 0: the operation of image collection and feature search is carried out all the time. If the same feature ID number is found in the fingerprint database, the operation will exit (0 means the cycle continues until the matching ID is found or the power is cut off).

1-0xFF: The generated features and fingerprint search were performed on the collected images. If the match is successful, the ID number and score of the match will be returned, and exit this instruction at the same time. If the match fails, repeat the previous operations for 1-0xff times. Exit after



corresponding error times. No matter what way, if the system does not detect the finger after sending the command or collecting the image again for more than 10 seconds, it will exit the command.

Example of AutoIdentify:

Send: EF 01 FF FF FF FF 01 00 08 32 03 00 C8 01 01 01 08

Return: EF 01 FF FF FF FF 07 00 08 00 01 00 00 00 00 10 EF 01 FF FF FF FF 07 00 08 00 02 00 00 00 00 11 EF 01 FF FF FF FF 07 00 08 00 03 00 00 00 3D 00 4F (Fingerprint ID and score)

Acknowledge package format:

| 2 bytes | 4 bytes        | 1 byte             | 2 bytes        | 1 byte            | 1 byte | 2 bytes         | 2 bytes     | 2 bytes  | Note             |
|---------|----------------|--------------------|----------------|-------------------|--------|-----------------|-------------|----------|------------------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Step   | Position Number | Score       | Checksum |                  |
| 0xEF01  | xxxx           | 0x07               | 0x0008         | X                 | 1      | 00              | 00          | Sum      | Collect Image    |
| 0xEF01  | xxxx           | 0x07               | 0x0008         | X                 | 2      | 00              | 00          | Sum      | Generate Feature |
| 0xEF01  | xxxx           | 0x07               | 0x0008         | X                 | 3      | Model ID        | Match score | Sum      | Search           |

Confirmation code=0x00 set successfully

Confirmation code=0x01 set fails

Confirmation code=0x09 failed to search fingerprint

Confirmation code=0x0b the ID is out of range

Confirmation code=0x22 fingerprint template is empty

Confirmation code=0x24 fingerprint library is empty

Confirmation code=0x26 times out

## Other instructions

### To generate a random code      GetRandomCode

Description: to command the Module to generate a random number and return it to upper computer;

Input Parameter: none

Return Parameter: Confirmation code (1 byte)+RandomCode

Instruction code: 14H

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 01H                | 0003H          | 14H              | 0018H    |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 4 bytes       | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|---------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Random number | Checksum |

|        |      |     |       |     |            |     |
|--------|------|-----|-------|-----|------------|-----|
| 0xEF01 | xxxx | 07H | 0007H | xxH | RandomCode | sum |
|--------|------|-----|-------|-----|------------|-----|

Note: Confirmation code=00H: generation success;

Confirmation code=01H: error when receiving package;

## To read information page      ReadInfPage

Description: read information page(512bytes)

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 16H

Command (or instruction) package format:

|         |                |                    |                |                  |          |
|---------|----------------|--------------------|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Instruction code | Checksum |
| 0xEF01  | xxxx           | 01H                | 0003H          | 16H              | 001AH    |

Acknowledge package format:

|         |                |                    |                |                   |          |
|---------|----------------|--------------------|----------------|-------------------|----------|
| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0fH: can not transfer the following data packet;

2. The upper computer sends the command packet, the module sends the acknowledge packet first, and then sends several data packet.

3.Packet Bytes N is determined by Packet Length. The value is 128 Bytes before delivery.

4: The instruction doesn't affect buffer contents.

Data package format:

|         |                |  |                |                  |          |
|---------|----------------|--|----------------|------------------|----------|
| 2 bytes | 4bytes         | 1 byte   | 2 bytes        | N bytes          | 2 bytes  |
| Header  | Module address | Package identifier                               | Package length | Package content  | Checksum |
| 0xEF01  | xxxx           | 0x02- have following packet<br>0x08 - end packet | N+2            | Information page | sum      |

## To write note pad      WriteNotepad

Description: for upper computer to write data to the specified Flash page.Also see ReadNotepad;

Input Parameter: NotePageNum, user content (or data content)

Return Parameter: Confirmation code (1 byte)

Instruction code: 18H

Command (or instruction) package format:

|         |        |        |         |        |       |          |         |
|---------|--------|--------|---------|--------|-------|----------|---------|
| 2 bytes | 4bytes | 1 byte | 2 bytes | 1 byte | 1byte | 32 bytes | 2 bytes |
|---------|--------|--------|---------|--------|-------|----------|---------|

| Header | Module address | Package identifier | Package length | Instruction code | Page number | Data content | Checksum |
|--------|----------------|--------------------|----------------|------------------|-------------|--------------|----------|
| 0xEF01 | xxxx           | 01H                | 0x0024         | 18H              | 0x00-0x0F   | content      | sum      |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | Checksum |
| 0xEF01  | xxxx           | 07H                | 0003H          | xxH               | sum      |

Note: Confirmation code=00H: write success;

Confirmation code=01H: error when receiving package;

Confirmation code=18H: error when write FLASH

## To read note pad      ReadNotepad

Description: to read the specified page's data content;Also see **WriteNotepad**.

Input Parameter: NotePageNum

Return Parameter: Confirmation code (1 byte) + User content

Instruction code: 19H

Command (or instruction) package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte           | 1byte       | 2 bytes  |
|---------|----------------|--------------------|----------------|------------------|-------------|----------|
| Header  | Module address | Package identifier | Package length | Instruction code | Page number | Checksum |
| 0xEF01  | xxxx           | 01H                | 0004H          | 19H              | 0x00-0x0F   | Sum      |

Acknowledge package format:

| 2 bytes | 4bytes         | 1 byte             | 2 bytes        | 1 byte            | 32bytes      | 2 bytes  |
|---------|----------------|--------------------|----------------|-------------------|--------------|----------|
| Header  | Module address | Package identifier | Package length | Confirmation code | User content | Checksum |
| 0xEF01  | xxxx           | 07H                | 0x0023         | xxH               | User content | sum      |


Note: Confirmation code=00H: read success;

Confirmation code=01H: error when receiving package;

## VI Operation Process

### 6.1 Basic communication flow

#### 6.1.1 Process of the UART command package



功能实现示例 1：UART命令包的处理过程




### 6.1.2 UART Packet Sending Process

Before transmitting data packets, the UART should be received the instruction packet for transmitting data packets first, makes preparations for transmission, then sends a successful response packet, and finally starts transmitting the data packets. Packet mainly includes: packet header, chip address, packet identity, packet length, data and checksum.

There are two types of packet identifiers: 02H and 08H. 02H: indicates the data packet and subsequent packets. 08H: indicates the last packet, that is, the end packet. Data length is pre-set, mainly divided into: 32, 64, 128, and 256 four types.

For example, if the length of the data to be transmitted is 1K bytes and the preset length of the data packet is 128 bytes, the 1K bytes of data must be divided into eight data packets. Each packet includes: 2 bytes header, 4 bytes chip address, 1 bytes packet identifier, 2 bytes packet length, 128 bytes data and 2 bytes check sum, each packet length is 139 bytes.

In addition, of the eight packets, the packet ID of the first seven packets is 02H and the packet ID of the last end data packet is 08H. Finally, note that if the end packet does not reach 139 bytes in length, it is transmitted at the actual length and is not otherwise expanded to 139 bytes.



功能实现示例 2: UART 数据包的发送过程


### 6.1.3 UART packet receiving process

Before transmitting data packets, the UART should be received the instruction packet for transmitting data packets first, makes preparations for transmission, then sends a successful response packet, and finally starts transmitting the data packets. Packet mainly includes: packet header, chip address, packet identity, packet length, data and checksum.

There are two types of packet identifiers: 02H and 08H. 02H: indicates the data packet and subsequent packets. 08H: indicates the last packet, that is, the end packet. Data length is pre-set, mainly divided into: 32, 64, 128, and 256 four types.

For example, if the length of the data to be transmitted is 1K bytes and the preset length of the data packet is 128 bytes, the 1K bytes of data must be divided into eight data packets. Each packet includes: 2 bytes header, 4 bytes chip address, 1 bytes packet identifier, 2 bytes packet length, 128 bytes data and 2 bytes check sum, each packet length is 139 bytes.

In addition, of the eight packets, the packet ID of the first seven packets is 02H and the packet ID of the last end data packet is 08H. Finally, note that if the end packet does not reach 139 bytes in length, it is transmitted at the actual length and is not otherwise expanded to 139 bytes.




功能实现示例 3: UART 数据包的接收过程

## 6.2 General instruction communication flow

### 6.2.1 General instruction register fingerprint process

The fingerprint registration process mainly includes: obtaining images for registration, generating features, merging features and storing templates. Usually  $N = 2$  times.



功能实现示例 4：通用指令注册流程


When the registration logic is set to 1, register fingerprint. If the current fingerprint is similar to the fingerprint that has been included before, the confirmation code in the response packet that generates the feature command does not show success, but returns 28H, indicating that there is a correlation between the current fingerprint feature and the previous feature. It should be noted that the mutual comparison correlation is limited to the fingerprints included in this registration process, and will not be compared with the fingerprints in the fingerprint library.

When the registration logic is set to 2, register fingerprint. If the current fingerprint is not similar to the fingerprint that has been included before, the confirmation code in the response packet that generates the feature command does not show success, but returns 08H, indicating that there is no correlation between the current fingerprint feature and the previous feature. It should be noted that the mutual comparison correlation is limited to the fingerprints included in this registration process, and will not be compared with the fingerprints in the fingerprint library.

Whether it returns 28H or 08H, the current fingerprint feature has been successfully extracted, you can take a new map and generate features without changing the BufferID, or you can skip the current BufferID and include the next round of fingerprints.

### 6.2.2 General instruction verify fingerprint process

The fingerprint verification process of general instructions mainly includes: obtaining images for verification, generating features and searching fingerprints. When sending generated features and searching for fingerprints, BufferID is set to 1 by default.




功能实现示例 5：通用指令验证流程

### 6.2.3 Read a specified template upload to Flash Fingerprint Database


The whole process mainly includes: read template and upload templates.

BufferID is set to the default value 2 when reading template and uploading feature.




功能实现示例 7: 从 flash 指纹库中读取一个指定的模板上传

## 6.3 Automatic Register Fingerprint




## 6.4 Automatic Fingerprint Verification(Search)



## 6.5 Low power standby

For low-power standby scenarios, the host can cut off the main power supply of the module (can not cut off the touch-sensitive power supply). Once the module detects a finger, it outputs a signal in the IRQ signal. Then the host can power on the module to perform fingerprint identification.





## VII Reference Circuit

In low-power supply mode, the whole circuit is normally powered off. Use the finger detection function of the module to power on the whole machine. Please refer to the circuit form of **R307 (R307 is 5V power supply)**.

